

The Original
**Balloon
GIZMO**

BOUQUET UPGRADE KIT
ASSEMBLY INSTRUCTIONS



35082
Bouquet Upgrade Kit

0 91451 35082 0

Balloons Sold Separately



Pictured: 17" In-Ground Bouquet System (sold separately).



BOUQUET UPGRADE KIT (#35082) ASSEMBLY INSTRUCTIONS

THIS KIT IS NOT A STAND-ALONE SYSTEM!
(Use with Balloon Gizmo™ Bouquet Systems: 35037, 35038, 35039, or 35044)

PARTS LIST



A - 17" Balloon Gizmo™ Balloon (3 pieces)

Balloons Sold Separately



B - Standard Connector Clip (3 pieces)



C - Standard Rods (3 pieces)



D - Bouquet Bracket

TOOLS & TIPS

Air Inflator (sold separately)

Our High Power Inflator (#35057) is the perfect solution for your inflation needs.

Inflates balloons in seconds!

BEFORE beginning the assembly below, follow the original instructions that came with your full Balloon Gizmo™ Bouquet System.

NOTE: This kit requires three 17" Balloon Gizmo™ balloons (sold separately).

1. BEFORE INFLATING THE BALLOONS, insert a **Standard Connector Clip (B)** into the pocket located on the bottom of each **Balloon Gizmo™ Balloon (A)**.
2. Fold the balloon flaps over each connector clip (photo 1).
3. Attach a **Standard Rod (C)** to each balloon by aligning the square slots on the cup end of the rod with the teeth on the connector clip. Push pieces together until they click (photo 2).
4. Inflate each balloon until the surface is smooth and wrinkle free. **NOTE:** Slightly under-inflate in hot climates to allow space for air to expand.
5. Remove the wingnut from the top of the jumbo pole (from the bouquet system being upgraded).
6. Loosen the clamps on **Bouquet Bracket (D)** and slide it 2/3 of the way down the jumbo pole. **NOTE:** To slide the bracket, grip the arms on either side of the clamps, pull them slightly apart, and move the bracket into place (photo 3).
7. Using the method from Step 5, slide the second bouquet bracket (from the bouquet system being upgraded) 1/3 of the way down the jumbo pole. **NOTE:** The brackets should be spaced approximately one foot apart.
8. Rotate the upper bouquet bracket on the pole so that, when viewed from the top, the arms on each bracket are equally spaced apart (photo 4).

PHOTO 1



PHOTO 2




PHOTO 3






PHOTO 4



BOUQUET UPGRADE KIT (#35082) ASSEMBLY INSTRUCTIONS

PARTS LIST



TOOLS & TIPS

Air Inflator (sold separately)
Our High Power Inflator (#35057) is the perfect solution for your inflation needs.
Inflates balloons in seconds!

9. Insert the spiked end of the assembled jumbo rod and balloon (from the bouquet system being upgraded) into the opening on top of the jumbo pole. Secure in place by re-screwing the wingnut into the threaded hole at the top of the pole (photo 5).

10. Attach the six fully assembled rods and balloons (three are from the bouquet system being upgraded) to the bouquet brackets by aligning the locking peg on each rod with the slotted holes on the bracket. Slide each rod in and twist a ¼ turn counter-clockwise to lock in place (photo 6).

NOTE: The final placement of the balloons on the brackets will depend on the color and pattern desired.

11. Adjust the final vertical position of the upper and then the lower assembled bouquet brackets. Secure them in place by relocking the clamps (photo 7).

NOTE: When properly positioned, the balloons will nest together and the tops of the balloon(s) will lightly touch the bottom of the balloon(s) in the layer above.

PHOTO 5



PHOTO 6



PHOTO 7

